



### INSTALLATION



**1** Pull sleeve tightly over the carrier pipe until the carrier pipe stands out clearly against the sleeve

**2** Cut off sleeve in front of the carrier pipe with a sharp knife.



**3** Then pull sleeve over the carrier pipe up to the casing pipe (sleeve can be stretched about 10 %).

**4** Pull integrally moulded sleeve collar over the casing pipe (sleeve can be stretched about 10 %) and attach the sleeve to the casing pipe with the larger of the straps included in the delivery

**5** Wrap the annular space with the conical part of the S-shaped sleeve and attach it to the carrier pipe with the second strap.

**6** If only the smaller collar is used, the larger one can be cut, if necessary.

