



INSTALLATION



1

Cleaning the pipe surface. Sliding the wall collar and placing it in the place provided.

2

Place the straps and tighten with a screwdriver until the straps are tight.

3

The wall collar is now ready for embedding in concrete, sufficient compaction in the area of the wall collar must be ensured.



WARNING

Number of steel straps:

For wall collar up to pipe OD 315 mm. 2 steel straps, placement on both sides of the skit.

For wall collar from pipe OD 355 mm. 3 steel straps, placement on both sides of the skit and between the skits.

NOTE

- The collar is not a fixed point or bearing and therefore cannot absorb any mechanical forces.
- The minimum concrete coverage should not be less than 3 cm. Attention to cement data sheet B29 (self-compacting concrete), cement data sheet H10 (waterproof concrete).