



## INSTALLATION




1

Clean casing pipe/core drilling and carrier pipe. Carrier pipes must be suitable, dimensionally stable and without damage in the sealing area. Core drillings have to be made true to scale and with a smooth inner side.




2

We recommend coating core drillings with ProteX epoxy resin in order to protect the concrete and smoothen possible cavities/grooves.



3

Verify the casing pipe/core drilling and carrier pipe diameters based on the sealing kit data. Insert the Kompakt seal into the casing pipe or core drilling flush with the wall and insert the carrier pipe. Care must be taken to ensure the sealing insert is mounted on the outside of the building (tolerance for the carrier pipes).



4

In doing so, the nuts should preferably point to the inside in order to be accessible for subsequent tightening. The Kompakt seal split version is available for subsequent mounting. Tighten the nuts a few turns clockwise. Repeat this procedure two or three times, but not beyond the maximum torque (see table below). Tighten again after half an hour!

Nuts	Max. Torque	Torque for thin-walled plastic pipes	WR Super Soft	KTW
M 6	5 Nm	5 Nm	3 Nm	8 Nm
M 8	17 Nm for standard seal 20 Nm for standard seal	8 Nm for standard seal 15 Nm for standard seal	5 Nm	12 Nm
M 10	30 Nm	22 Nm	-	25 Nm
M 12	35 Nm	25 Nm	-	30 Nm

Nuts	Max. Torque	Torque for thin-walled plastic pipes	WR Super Soft	KTW
M 6	5 Nm	5 Nm	3 Nm	8 Nm
M 8	17 Nm for standard seal 20 Nm for standard seal	8 Nm for standard seal 15 Nm for standard seal	5 Nm	12 Nm
M 10	30 Nm	22 Nm	-	25 Nm
M 12	35 Nm	25 Nm	-	30 Nm



Wall opening ID	Carrier pipe OD
50 mm	6 - 12 mm
70 mm	20 - 41 mm
80 mm	20 - 50 mm
100 mm	15 - 65 mm
125 mm	55 - 78 mm
150 mm	46 - 110 mm
200 mm	88 - 160 mm
250 mm	135 - 210 mm
300 mm	178 - 226 mm
350 mm	224 - 282 mm
400 mm	270 - 330 mm